

## Loop Link communications interface



### 5909

- USB connection
- For PReset version 5.0 or higher



#### Description

- Loop Link 5909 is a communications interface for configuration and monitoring of PR electronics' PC-programmable devices using our PReset software.

#### Application

- The PReset software is used for the configuration of these devices: 5114, 5115, 5116, 5131, 5223, 5225, 5331, 5333, 5334, 5335, 5343, 5337, 5715, 6331, 6333, 6334, 6335, 6337
- Used in combination with 4501/4511 and 4590, the PReset software can also be used to save configurations from the following devices to the PC and download these configurations to subsequent devices of the same type: 3114, 4104, 4114, 4116, 4131, 4222, 9113, 9116

#### Technical characteristics

- Loop Link 5909 consists of a communication box with USB cable to the PC, necessary cables for connection to the devices, a CD-ROM with the configuration program PReset and an installation manual. The communication box is supplied from the USB port of the PC.

